midiphy
dream it yourself

MIDIbox SEQ v4+ Cheat Sheets

1. Overview

Left OLED Display
Play: Show the first 8 steps of a 16 step view (up to 256 steps)
Menu: Press the MENU button to show the menu page for each softkey

Right OLED Display
Play: Show the second 8 steps of a 16 step view (up to 256 steps)
Menu: Press the MENU button to show the menu page for each softkey

Activity Matrix Display
Load: displays session name
Play: Display modes:
- MIDI Velocity meter for each track
- Track Positions
- Current BPM

See UTILITY>Opt.> #26 to change modes

Displays

Parameter Adjustment Knobs

Steps/ General Purpose (GP) Keys

Select Mode Keys

Function Keys

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16

Layer
Param Trigger
Track Instr.
Step Mute
Bookm. Phrase
Select Mode

Solo Metr. Loop Rec. Live

Copy Paste Clear Move Scroll Fast All Shift < > Exit Menu Edit Pattern Song Utility

Data Wheel
Parameter:
increment or decrement value
EDIT:
scroll cursor, change step view, change value
MENU:
Scroll through all Menu Options
SCRUB:
Shift step or note position

Beat LED
- Play: flashes green on every first beat of a measure
- Play: flashes red on every other beat

Rear Panel

Mac, PC or USB Power Supply (2A)

USB Mode Switch

USB OTG for future applications

Footswitch Connector
- enables record mode while pressed
- short tap deletes track

4x MIDI OUT (MIDIbox I2C Module)

4x MIDI IN & 4x MIDI OUT

1x MIDI OUT / BLM (Button/LED Matrix), also supports the new midiphy MatriX

USB OTG Gate In Reset

IIC1 IIC2 IIC3 IIC4 IN1 OUT1 IN2 OUT2 IN3 OUT3 IN4/PWR OUT4/BLM

Reset Button

SD Card Slot
Supports Class 4 cards or better

Connector for optional Eurorack Interface Expansion (CV/Gate/Clock/Trigger)

DIN-8 connector supports powered connection

Status LEDs
- Sending MIDI Data
- Receiving MIDI Data
- SD Card ready
- Device Status

oddsfilr 08/21.5